



HANDI-FOAM[®] POLYURETHANE CLEANER is a cleaning solvent used to dissolve uncured polyurethane foam sealant and adhesive. Uniquely designed for use with our one-component dispensing units as well as for general cleaning purposes.

RECOMMENDED FOR CLEANING:

- POLYMER 7" DISPENSING UNIT
- STEEL DISPENSING UNIT
- CONVERTIBLE DISPENSING UNIT

GENERAL CLEANING INSTRUCTIONS:

- ⇒ Wear impervious gloves, goggles and work clothes during use. Use with adequate ventilation.
- ⇒ Shake can well before spraying or attaching to a dispensing unit.
- ⇒ Do not use in horizontal position.
- ⇒ Insert red spray activator onto the valve stem of the can.
- ⇒ With arrow pointing towards surface to be cleaned, slowly depress red activator to spray solvent.
- ⇒ Do not use on painted surfaces or any untested substrate



DISPENSING UNIT CLEANING

- ⇒ Follow general cleaning instructions after every can to remove any fresh foam from the dispensing unit coupling and the barrel opening before attaching a new can.
- ⇒ It is not necessary to flush the dispensing unit after every can. Always replace the empty product container immediately with a fresh can, and, to maintain the dispensing unit in good working order, follow these instructions after every 10-20 cans, or prior to prolonged storage or repair.
- ⇒ While holding red spray activator aside, screw Handi-Foam[®] polyurethane cleaner can onto the dispensing unit coupling until it will go no further. Do not over tighten.
- ⇒ Carefully pull the gun trigger until solvent extrudes from the gun. Release the gun trigger and let solvent soak in gun for one or two minutes.
- ⇒ Pull gun trigger and dispense solvent into suitable container (can, box, etc). If necessary, repeat procedure two or three times, until only clear solvent appears from nozzle.

